

Quick Start for the LCIC-WIM / CatchWeigher

(For full documentation refer to LCIC-WIM.PDF & LCIC-WIM-CatchWeigher.PDF.)

1. Copy the supplied CD to your disk.
2. Connect the LCIC-WIM board to your PC using the USB cable (supplied).
3. In the 'Found New Hardware Wizard' browse to the
"FTDI - VCP (Virtual COM Port) Driver"
folder in your copy of the CD.
4. It might occur that after you click Finish you'll have to repeat the procedure once more.
5. Run the following setups:
 - * LCIC-WIM-CALIBRATION
 - * LCIC-WIM-MONITOR
 - * LCIC-WIM-SETTINGS
 - * LCIC-WIM-CATCH-WEIGHER
 - * LCIC-WIM-FILTERS-SIMULATOR
6. Run the Calibration program (LCIC-WIM-CALIBRATION).
7. Run the Settings program (LCIC-WIM-SETTINGS) and set the general parameters as described in section 3.3 of LCIC-WIM.PDF.
8. Run the CatchWeigher program (LCIC-WIM-CATCH-WEIGHER) and refer to the instructions in 'LCIC-WIM-CatchWeigher.pdf'.